

SmartNode 4520 & 4110 Series **VoIP Gateway Routers**

Getting Started Guide



Sales Office: +1 (301) 975-1000
Technical Support: +1 (301) 975-1007
E-mail: support@patton.com
WWW: www.patton.com

Document Number: **132021U Rev. A**
Part Number: **07MD4524-UG**
Revised: **September 22, 2003**

Patton Electronics Company, Inc.

7622 Rickenbacker Drive
Gaithersburg, MD 20879 USA
tel: +1 (301) 975-1000
fax: +1 (301) 869-9293
support: +1 (301) 975-1007
web: www.patton.com
e-mail: support@patton.com

Trademark Statement

The terms *SmartWare*, *SmartView*, and *SmartNode* are trademarks of Patton Electronics Company. All other trademarks presented in this document are the property of their respective owners.

Copyright © 2003, Patton Electronics Company. All rights reserved.

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

Warranty Information

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

Patton Electronics warrants all SmartNode Series router components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of the shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If the product fails to perform as warranted, your sole recourse shall be repair or replacement as described above. Under no condition shall **Patton Electronics** be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product. **Patton Electronics** specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

Contents

Contents	3
Compliance information	7
Radio and TV interference	7
CE notice	7
EU declaration of conformity	7
Service	7
About this guide	9
Audience	9
Structure	9
Precautions	10
Safety when working with electricity	10
Preventing electrostatic discharge damage	11
General observations	11
Typographical conventions used in this document	12
General conventions	12
Mouse conventions	13
1 General information	15
SmartNode Series VoIP routers overview	16
SmartNode 4520 Series router	17
Ports descriptions	18
LED descriptions	19
SmartNode 4110 Series router	20
Ports descriptions	21
LED descriptions	22
2 Applications Overview	25
Introduction	26
Applications for SmartNode 4110 Series	26
H.323 terminal media gateway	26
Application—Private line automatic ringdown (PLAR)	27
Application—Enterprise campus BRI to FXS telephony extension	27
Application—PBX toll bypass gateway	28
Applications for SmartNode 4520 Series	29
Application—Desktop or LAN segment QoS	29
Application—Point-to-point WAN QoS Switch	29
Applications in combination with FXO models	30
Application—SOHO off-premise extension	30
3 Installation	31
Planning the installation	32
Installation checklist	33

Site log	34
Network information	34
Network Diagram	34
IP related information	34
Software tools	34
Power source	34
Location and mounting requirements	35
Installing the gateway router	35
Mounting the gateway router	35
Connecting cables	35
Installing an interface cable on the router's FXS interface port	36
Installing the Ethernet cable	38
Installing the power cord	40
4 Getting started with the SmartNode.....	41
Introduction	42
1. Configure IP address	43
Power connection and default configuration	43
Connect with the serial interface	43
Login	44
Changing the IP address	44
2. Connect the SmartNode to the network	45
3. Load configuration	45
Additional information	46
5 Monitoring Status	47
Status LEDs	48
6 Contacting Patton for assistance	51
Introduction	52
Contact information	52
Warranty Service and Returned Merchandise Authorizations (RMAs)	52
Warranty coverage	52
Out-of-warranty service	52
Returns for credit	52
Return for credit policy	53
RMA numbers	53
Shipping instructions	53
A Specifications	55
DSP	56
Voice connectivity	56
Connectivity	56
Voice processing (signalling dependent)	56
Fax and modem support	56
Voice Signalling	57

Voice Routing—Session Router	57
IP services	57
Management	58
Operating Environment	58
Operating temperature	58
Operating humidity	58
System	58
Compliance	58
Dimensions	58
Weight	59
Power supply	59
AC version	59
DC version	59
Power dissipation	59
B Cabling	61
Introduction	62
Serial console	62
Ethernet 10Base-T and 100Base-T	63
Analog FXS	64
C Port pin-outs	65
Introduction	66
Console port	66
Ethernet 10Base-T and 100Base-T port	66
FXS port	66

Compliance information

Radio and TV interference

The SmartNode Series router generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer’s instructions—may cause interference to radio and television reception. The SmartNode router have been tested and found to comply with the limits for a Class A computing device in accordance with specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the SmartNode Series router does cause interference to radio or television reception, which can be determined by disconnecting the unit, the user is encouraged to try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

CE notice

The CE symbol on your Patton Electronics equipment indicates that it is in compliance with the Electromagnetic Compatibility (EMC) directive and the Low Voltage Directive (LVD) of the European Union (EU). A Certificate of Compliance is available on our web site at www.patton.com, or by contacting Technical Support.

EU declaration of conformity

The EU Directive covered by this Declaration

- **99/5/EC**—Guideline of the European Parliament and the Committee for the Harmonization of the Legal Regulations of the Member States concerning radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

SmartNode routers comply with the requirements of the above EU directive by meeting the following standards:

- Safety Compliance: EN 60950 (Edition 1997)
- EMC Compliance: EN 55022 (Edition 1998), EN 55024 (Edition 1998)

Service

All warranty and non-warranty repairs must be returned freight prepaid and insured to Patton Electronics. All returns must have a Return Materials Authorization number on the outside of the shipping container. This number may be obtained from Patton Electronics Technical Services at:

- Tel: **+1 (301) 975-1007**
- Email: **support@patton.com**
- URL: **www.patton.com**

Note Packages received without an RMA number will not be accepted.

About this guide

This guide describes the SmartNode 4110 and 4520 Series hardware, installation and basic configuration. For detailed software configuration information refer to the *SmartWare Software Configuration Guide* and the available Configuration Notes.

Audience

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

Structure

This guide contains the following chapters and appendices:

- [Chapter 1](#) provides information about router features and capabilities
- [Chapter 2](#) contains an overview describing router operation and applications
- [Chapter 3](#) provides quick start installation procedures
- [Chapter 4](#) describes getting started with the SmartNode router
- [Chapter 5](#) contains definitions for the LED status indicators
- [Chapter 6](#) contains information on contacting Patton technical support for assistance
- [Appendix A](#) contains specifications for the routers
- [Appendix B](#) provides cable recommendations
- [Appendix C](#) describes the router's ports and pin-outs

For best results, read the contents of this guide *before* you install the router.

Precautions

Notes and cautions, which have the following meanings, are used throughout this guide to help you become aware of potential Router problems. *Warnings* relate to personal injury issues, and *Cautions* refer to potential property damage.

Note Calls attention to important information.



The shock hazard symbol and **WARNING** heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.



The alert symbol and **WARNING** heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



The shock hazard symbol and **CAUTION** heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



The alert symbol and **CAUTION** heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.

Safety when working with electricity



Mains Voltage: Do not open the case when the power cord is connected. For systems without a power switch, line voltages are present within the power supply when the power cord is connected.



Hazardous network voltages are present in WAN ports regardless of whether power to the SmartNode is ON or OFF. To avoid electric shock, use caution when near WAN ports. When detaching cables, detach the end away from the SmartNode first.



Do not work on the system or connect or disconnect cables during periods of lightning activity.



Before opening the chassis, disconnect the telephone network cables to avoid contact with telephone line voltages.



Ultimate disposal of this equipment must be handled according to all applicable national laws and regulations.

Preventing electrostatic discharge damage

When starting to install interface cards place the interface card on its shielded plastic bag if you lay it on your bench.



Electrostatic Discharge (ESD) can damage equipment and impair electrical circuitry. It occurs when electronic printed circuit cards are improperly handled and can result in complete or intermittent failures. Do the following to prevent ESD:

- Always follow ESD prevention procedures when removing and replacing cards.
- Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the clip to an unpainted surface of the chassis frame to safely channel unwanted ESD voltages to ground.
- To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.

General observations

- Clean the case with a soft slightly moist anti-static cloth
- Place the unit on a flat surface and ensure free air circulation
- Avoid exposing the unit to direct sunlight and other heat sources
- Protect the unit from moisture, vapors, and aggressive liquids


Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions

Convention	Meaning
Garamond blue type	Indicates a cross-reference hyperlink that points to a figure, graphic, table, or section heading. Clicking on the hyperlink jumps you to the reference. When you have finished reviewing the reference, click on the Go to Previous View button  in the Adobe® Acrobat® Reader toolbar to return to your starting point.
Futura bold type	Commands and keywords are in boldface font.
<i>Futura bold-italic type</i>	Parts of commands, which are related to elements already named by the user, are in <i>boldface italic</i> font.
<i>Italicized Futura type</i>	Variables for which you supply values are in <i>italic</i> font
Futura type	Indicates the names of fields or windows.
Garamond bold type	Indicates the names of command buttons that execute an action.
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.
[]	Elements in square brackets are optional.
{a b c}	Alternative but required keywords are grouped in braces ({ }) and are separated by vertical bars ()
blue screen	Information you enter is in blue screen font.
screen	Terminal sessions and information the system displays are in screen font.
node	The leading IP address or nodename of a SmartNode is substituted with node in <i>boldface italic</i> font.
SN	The leading SN on a command line represents the nodename of the SmartNode
#	An hash sign at the beginning of a line indicates a comment line.

Mouse conventions

The following conventions are used when describing mouse actions:

Table 2. Mouse conventions

Convention	Meaning
Left mouse button	This button refers to the primary or leftmost mouse button (unless you have changed the default configuration).
Right mouse button	This button refers the secondary or rightmost mouse button (unless you have changed the default configuration).
Point	This word means to move the mouse in such a way that the tip of the pointing arrow (referred to as the <i>cursor</i>) on the screen ends up resting at the desired location.
Click	Means to press and release the left or right mouse button one time quickly (as instructed in the procedure). Make sure you do not move the cursor while clicking a mouse button.
Double-click	Means to press and release the same mouse button two times quickly. Make sure you do not move the cursor while clicking a mouse button.
Drag	This word means to place the cursor and then hold down the left or right mouse button (as instructed in the procedure) as you move the mouse to a new location. When you have moved the cursor to the desired location, you can release the mouse button.

Chapter 1

General information

Chapter contents

SmartNode Series VoIP routers overview.....16

SmartNode 4520 Series router17

Ports descriptions18

LED descriptions19

SmartNode 4110 Series router20

Ports descriptions21

LED descriptions22

SmartNode Series VoIP routers overview

The SmartNode 4520 and 4110 Series VoIP Gateway Routers (see [figure 1](#)) combine IP routing, VPN/Security, and Quality of Service for up to 8 transparent voice and FAX calls over any IP or PSTN network. Leverage low-cost IP services with packet-voice for complete branch office voice and data connectivity.



Figure 1. SmartNode Router (SmartNode 4524 shown)

The SmartNode 4520 Series Gateway Routers are equipped with two 10/100Base-T Ethernet ports, providing IP network connectivity plus prioritized Ethernet switching, IP routing, Firewall functions, LAN data services and extensive IP QoS functions.

The SmartNode 4110 Series Media Gateways are equipped with a single 10/100Base-T Ethernet port that provides IP network connectivity.

A SmartNode Gateway performs the following major functions:

- Voice termination and switching via two to eight analog interfaces (FXS voice ports).
- Voice over IP (VoIP) conversion of telephone circuits into Internet Protocol (IP) data streams. VoIP is supported in accordance with standard H.323, SIP¹ or MGCP¹ protocols.
- IP Routing (4520 Series only) with IP layer Quality of Service (QoS) support for mixed voice and data traffic.
- Ethernet Switching (4520 Series only) with Ethernet layer Quality of Service (QoS) support for mixed voice and data traffic.

Section “[SmartNode 4520 Series router](#)” on page 17 provides more information on the SmartNode 4520 Series ports and LEDs. Section “[SmartNode 4110 Series router](#)” on page 20 describes the SmartNode 4110 Series ports and LEDs.

1. May require special software loads and/or configuration. Contact Patton Technical Support for details.

SmartNode 4520 Series router

The SmartNode 4520 Series is a compact VoIP Gateway Router, which supports two to eight voice channels. The following models (each equipped with two 10/100Base-T Ethernet ports) are available (see [figure 2](#)):

- SmartNode 4522 (2 FXS voice ports)
- SmartNode 4524 (4 FXS voice ports)
- SmartNode 4526 (6 FXS voice ports)
- SmartNode 4528 (8 FXS voice ports)

Note The SmartNode 4526 and 4528 are available with external power only.




Figure 2. 4520 Series rear panels




Figure 3. SmartNode 4520 Series power input connectors

Ports descriptions

The SmartNode 4520 Series rear panel ports are described in [table 3](#).

Table 3. Rear panel ports

Port	Location	Description
10/100 Ethernet ETH 0/0 & ETH 0/1	Rear panel	RJ-45 connectors (see figure 2 on page 17) that connect the router to an Ethernet device (e.g., a cable or DSL modem, LAN hub or switch).
Voice Ports, FXS	Rear panel	<p>FXS RJ-11/12 connectors (see figure 2 on page 17) that connect the router with an FXO port (a telephone for example). EuroPOTS support (ETSI EG201 188). Configured per model as follows:</p> <ul style="list-style-type: none"> • SmartNode 4522—0/0, 0/1 • SmartNode 4524—0/0, 0/1, 0/2, 0/3 • SmartNode 4526—0/0, 0/1, 0/2, 0/3, 0/4, 0/5 • SmartNode 4528—0/0, 0/1, 0/2, 0/3, 0/4, 0/5, 0/6, 0/7
Power	Rear panel	<p>The gateway is available in a DC or AC power input version (see figure 3), labeled as follows:</p> <ul style="list-style-type: none"> • AC version (Internal power supply): 100–240 VAC, 50/60 Hz • AC version (External power supply): 100–240 VAC, 50/60 Hz • DC version: 12 VDC
Console	Front panel	Used for service and maintenance, the Console port (see figure 4 on page 19), an RS-232 RJ-45 connector, connects the router to a serial terminal such as a PC or ASCII terminal (also called a dumb terminal).




Figure 4. SmartNode 4520 Series front panels

LED descriptions

This section describes the SmartNode 4520 Series front panel LEDs (see [figure 4](#)).

Note If an error occurs, all LEDs will flash once per second.

- **Power**—When lit, indicates power is applied. Off indicates no power applied.
- **Run**—When lit, indicates normal operation. Flashes during boot (startup).
- **VoIP Link**—When lit, indicates the gateway is registered on a gatekeeper, media gateway controller, associated to a remote unit, or has an active VoIP connection. Off indicates the unit is not configured or registered and has no active VoIP connection. Flashing green indicates that the unit is trying or has failed to associate/register.
- **FXS (each port)**—Off indicates on-hook condition. Solid green when off-hook. Flashes to follow ring cadence.
- **Ethernet (each port):**
 - **Link:** Lit when Ethernet link is up.
 - **100M:** On when 100-Mbps Ethernet is selected.
 - **Activity:** Flashes when data is received or transmitted from the unit to the LAN.

SmartNode 4110 Series router

The SmartNode 4110 Series is a compact VoIP gateway, which supports two to eight voice channels. The following models (each equipped with one 10/100Base-T Ethernet port) are available (see [figure 5](#)):

- Model 4112 (2 FXS voice ports)
- Model 4114 (4 FXS voice ports)
- Model 4116 (6 FXS voice ports)
- Model 4118 (8 FXS voice ports)

Note The SmartNode 4116 and 4118 are available with external power only.




Figure 5. 4110 Series rear panels

Ports descriptions

The SmartNode 4110 Series rear panel ports are described in [table 4](#).

Table 4. Rear panel ports

Port	Location	Description
10/100 Ethernet ETH 0/0	Rear panel	RJ-45 connector (see figure 5 on page 20) that connects the router to an Ethernet device (a cable or DSL modem, LAN hub or switch, for example).
Voice Ports, FXS	Rear panel	<p>FXS RJ-11/12 connectors (see figure 5 on page 20) that connect the router with an FXO port (a telephone for example). EuroPOTS support (ETSI EG201 188). Configured per model as follows:</p> <ul style="list-style-type: none"> • Model 4112—0/0, 0/1 • Model 4114—0/0, 0/1, 0/2, 0/3 • Model 4116—0/0, 0/1, 0/2, 0/3, 0/4, 0/5 • Model 4118—0/0, 0/1, 0/2, 0/3, 0/4, 0/5, 0/6, 0/7
Power	Rear panel	<p>The gateway is available in a DC or AC power input version (see figure 6), labeled as follows:</p> <ul style="list-style-type: none"> • AC version (Internal power supply): 100–240 VAC, 50/60 Hz • AC version (External power supply): 100–240 VAC, 50/60 Hz • DC version: 12 VDC
Console	Front panel	Used for service and maintenance, the Console port (see figure 7 on page 22), an RS-232 RJ-45 connector, connects the router to a serial terminal such as a PC or ASCII terminal (also called a dumb terminal).




Figure 6. SmartNode 4110 Series power input connectors




Figure 7. SmartNode 4110 Series front panels

LED descriptions

This section describes the SmartNode 4110 Series front panel LEDs.

Note If an error occurs, all LEDs will flash once per second.

- **Power**—When lit, indicates power is applied. Off indicates no power applied.
- **Run**—When lit, indicates normal operation. Flashes once per second during boot (startup).

- **VoIP Link**—When lit, indicates the gateway is registered on a gatekeeper, media gateway controller, associated to a remote unit, or has an active VoIP connection. Off indicates the unit is not configured or registered and has no active VoIP connection. Flashing green indicates that the unit is trying or has failed to associate/register.
- **FXS (each port)**—Off indicates on-hook condition. Solid green when off-hook. Flashes to follow ring cadence.
- **Ethernet (each port):**
 - **Link:** Lit when Ethernet link is up.
 - **100M:** On when 100-Mbps Ethernet is selected.
 - **Activity:** Flashes when data is received or transmitted from the unit to the LAN.

Chapter 2 **Applications Overview**

Chapter contents

Introduction	26
Applications for SmartNode 4110 Series	26
H.323 terminal media gateway	26
Application—Private line automatic ringdown (PLAR)	27
Application—Enterprise campus BRI to FXS telephony extension	27
Application—PBX toll bypass gateway	28
Applications for SmartNode 4520 Series	29
Application—Desktop or LAN segment QoS	29
Application—Point-to-point WAN QoS Switch	29
Applications in combination with FXO models	30
Application—SOHO off-premise extension	30

Introduction

Patton's SmartNode Media Gateway Routers deliver all the features for advanced multiservice voice and data network applications. They combine high quality voice over IP with powerful Quality of Service routing and switching functions to make professional and reliable VoIP networks. This chapter describes typical applications for which the routers are uniquely suited.

Applications for SmartNode 4110 Series

The SmartNode 4110 Series, equipped with a single Ethernet port, provide gateway and over-IP line extension services.

H.323 terminal media gateway

All models provide *voice over IP* and *FAX over IP* services for integration into a gateway/gatekeeper network (see figure 8). The SmartNode 4110 Series router supports automatic registration to a gatekeeper as part of a PBX call manager and offers regular extension services.

A very simple installation for this application requires only the configuration of extension numbers for each port. The rest (IP address through DHCP and GK discovery through RAS) is automatic.




Figure 8. H.323 terminal gateways

Application—Private line automatic ringdown (PLAR)

Using two FXS models back-to-back a private hot-line can be created (see [figure 9](#)). These can be found in use as courtesy phones at ATM's, information kiosks, and emergency assistance pedestals. In this operation, when one handset is picked-up, the far immediately begins ringing. When the far-end handset is picked-up the speech path is completed. The link supports voice, fax Gr.3 (2.4–14.4 kbps) with T.38 or fax bypass, or modem connections using a G.711 codec.




Figure 9. FXS to FXS extension

Application—Enterprise campus BRI to FXS telephony extension

In combination with the Patton SmartNode 1000 and 2000 Series models the FXS gateways provide ISDN BRI to FXS extensions over IP (see [figure 10](#)).




Figure 10. BRI to FXS extension

Application—PBX toll bypass gateway

The gateways can be used to provide toll bypass over an IP WAN (see [figure 11](#)). The call routing in this case is provided by the PBX systems. A call routed to the FXS gateway can be relayed on a port-to-port basis to the remote gateway or on a dialed number basis.

Note With the use of FXS ports extension dialing on the secondary side must be done through two stage dialling (DTMF relay).




Figure 11. Toll bypass

Applications for SmartNode 4520 Series

These models have dual 10/100Base-T Ethernet ports. The second Ethernet port provides Ethernet and IP layer QoS services. Voice prioritization and rate limitation to avoid network congestion and the respective voice quality degradation.

Application—Desktop or LAN segment QoS

These models can be used by the network administrator to provide QoS tagging and management for individual desktops or LAN segments.




Figure 12. Desktop/Segment QoS Switch/GW

Application—Point-to-point WAN QoS Switch

The 4520 Series router can be used by the network administrator to provide QoS tagging and management point-to-point WAN links (see [figure 12](#)). The following data forwarding modes are supported:

- Ethernet switching: applicable for wire-speed switching at 10 or 100 Mbps useful in LAN segmentation, LAN extension (VDSL, fiber) or fiber access. In this mode hardware 802.1p prioritization is available but no software based queuing or rate limiting features.¹
- Bridging: useful for speeds less than 10 Mbps (DSL, leased-line bridges) where network administration and routing can be simplified by inserting a bridge instead of a router (e.g. in combination with VPN-Firewall). Software based QoS mechanisms such as rate limiting and queuing can be applied in this mode.¹
- Routing: useful for speeds less than 10 Mbps where the SmartNode provides routing service such as NAT, ACL, DHCP, PPPoE etc. and the full software based QoS functionality of SmartWare.

Note The layer 2 QoS switch cannot provide downstream QoS for networks connected to an IP WAN where various sources can congest the downstream.

1. Availability depending on SmartWare release and configuration.

Applications in combination with FXO models

The FXO models will enable the provisioning of POTS (FXS to FXO) extension over any existing Ethernet/IP network. The FXS ports will allow a standard POTS handset to seamlessly connect to a remote PSTN line or PBX extension port over a packet network. Following the model of extension, all of PBX functions are transparently carried over the network end-to-end (hook flash, CLID, DTMF, etc.).

Application—SOHO off-premise extension

For a SOHO/telecommuter the SmartNode 4520 Series router can provide an off-premise extension to the corporate network. Now the remote user will appear to be local and enjoy all of the services available to local telephony users—such as station-to-station dialing, outside trunk access, and voice mail. Additionally, the home user can take advantage of corporate dialing rates. This deployment does not require modification to the PBX/infrastructure.

Chapter 3 **Installation**

Chapter contents

Planning the installation	32
Installation checklist	33
Site log	34
Network information	34
Network Diagram	34
IP related information	34
Software tools	34
Power source	34
Location and mounting requirements	35
Installing the gateway router.....	35
Mounting the gateway router	35
Connecting cables	35
Installing an interface cable on the router's FXS interface port	36
Installing the Ethernet cable	38
Installing the power cord	40

Planning the installation

Before you start the actual installation, it is strongly recommended that you gather all the information needed to install and setup the device. See [table 5](#) for an example of what pre-installment checks you might need to carry out. Having carried out the pre-installation checks enables you to install and set up your gateway router into an existing infrastructure with confidence.

Note When setting up your gateway router consider cable length limitations, and potential electromagnetic interference (EMI) as defined by the applicable local and international regulations. Ensure that your site is properly prepared before beginning installation.

Before installing the gateway router device, the following tasks should be completed:

- **Create a network diagram** (see section [“Network information”](#) on page 34)
- **Gather IP related information** (see section [“IP related information”](#) on page 34 for more information)
- **Install the hardware and software needed to configure the SmartNode.** (See section [“Software tools”](#) on page 34)
- **Verify power source reliability** (see section [“Power source”](#) on page 34).

When you finish preparing for gateway router installation, go to section [“Installing the gateway router”](#) on page 35 to install the device.

Installation checklist

The installation checklist (see [table 5](#)) lists the tasks for installing a SmartNode 4520 or 4110 Series router. Make a copy of this checklist and mark the entries as you complete each task. For each SmartNode 4520 or 4110 Series router, include a copy of the completed checklist in your site log.

Table 5. Installation checklist

Task	Verified by	Date
Network information available & recorded in site log		
Environmental specifications verified		
Site power voltages verified		
Installation site pre-power check completed		
Required tools available		
Additional equipment available		
All printed documents available		
SmartWare release & build number verified		
Rack, desktop, or wall mounting of chassis completed		
Initial electrical connections established		
ASCII terminal attached to console port		
Cable length limits verified		
Initial configuration performed		
Initial operation verified		

Site log

Patton recommends that you maintain a site log to record all actions relevant to the system, if you do not already keep such a log. Site log entries should include information such as listed in [table 6](#).

Table 6. Sample site log entries

Entry	Description
Installation	Make a copy of the installation checklist and insert it into the site log
Upgrades and maintenance	Use the site log to record ongoing maintenance and expansion history
Configuration changes	Record all changes and the reasons for them
Maintenance	Schedules, requirements, and procedures performed
Comments	Notes, and problems
Software	Changes and updates to SmartWare software

Network information

Network connection considerations that you should take into account for planning are provided for several types of network interfaces are described in the following sections.

Network Diagram

Draw a network overview diagram that displays all neighboring IP nodes, connected elements and telephony components.

IP related information

Before you can set up the basic IP connectivity for your SmartNode 4000 series you should have the following information:

- IP addresses used for Ethernet LAN and WAN ports
- Subnet mask used for Ethernet LAN and WAN ports
- IP addresses of central H.323 Gatekeeper (if used)
- IP addresses of central PSTN Gateway for H.323 and/or ISoIP based calls
- IP addresses of central TFTP Server used for configuration upload and download

Software tools

You will need a PC (or equivalent) with a VT-100 emulation program (e.g. HyperTerminal) to configure the software on your SmartNode router.

Power source

If you suspect that your AC power is not reliable, for example if room lights flicker often or there is machinery with large motors nearby, have a qualified professional test the power. Install a power conditioner if necessary.

Location and mounting requirements

The SmartNode router is intended to be placed on a desktop or similar sturdy, flat surface that offers easy access to the cables. Allow sufficient space at the rear of the chassis for cable connections. Additionally, you should consider the need to access the unit for future upgrades and maintenance.

Installing the gateway router

SmartNode gateway router installation consists of the following:

- Placing the device at the desired installation location (see section “[Mounting the gateway router](#)” on page 35)
- Installing the interface and power cables (see section “[Connecting cables](#)” on page 35)

When you finish installing the SmartNode, go to chapter 4, “[Getting started with the SmartNode](#)” on page 41.

Mounting the gateway router

Place the router on a desktop or similar sturdy, flat surface that offers easy access to the cables. The router should be installed in a dry environment with sufficient space to allow air circulation for cooling.

Note For proper ventilation, leave at least 2 inches (5 cm) to the left, right, front, and rear of the SmartNode gateway router.

Connecting cables



Do not work on the system or connect or disconnect cables during periods of lightning activity.

Installing router cables takes place in the following order:

1. Installing the RJ-11 voice port (FXS) cable or cables (see “[Installing an interface cable on the router’s FXS interface port](#)”)
2. Installing the 10/100 Ethernet port cable or cables (see “[Installing the Ethernet cable](#)” on page 38)
3. Installing the power input (see “[Installing the power cord](#)” on page 40)

Installing an interface cable on the router's FXS interface port

The gateway comes with at least two FXS voice ports (see [figure 13](#)) located on the back of the router. The FXS interfaces are connected to analog devices via cables (see [figure 14](#)) terminated with RJ-11 connectors (see [figure 15](#) and [table 7](#) on page 37 for pin-out information).




Figure 13. Rear view showing location of Ethernet and FXS connectors (SmartNode 4520 shown)




Figure 14. Analog FXS connection




Figure 15. RJ-11 pinout diagram

Table 7. RJ-11 socket

Pin	Signal
3	Ring (-)
4	Tip (+)




Figure 16. Router front panel LEDs and Console port locations (SmartNode 4524 shown)

Installing the Ethernet cable

The SmartNode 4520 Series has automatic MDX (auto-cross-over) detection and configuration on the Ethernet ports. Any of the two ports can be connected to a host or hub/switch with a straight-through wired cable (see [figure 17](#)). Ethernet devices (10Base-T or 100Base-T) are connected to the SmartNode's Ethernet ports (see [table 8](#) for port pin-out listing) via a cable terminated with RJ-45 plugs. A cross-over cable is only required when connecting SmartNode 4110 Series devices to a host (see [figure 18](#) on page 39).

Table 8. Ethernet 10/100Base-T (RJ-45) port pin-outs

Pin	Signal
1	TX+
2	TX-
3	RX+
6	RX-

Note Pins not listed are not used.




Figure 17. Connecting to a hub




Figure 18. Connecting to a host (cross-over cable required for SmartNode 4110 Series only)

Installing the power cord

The router comes with an internal or external power supply. This section describes installing the power cord into the router. Do the following:

Note *Do not connect the other end of the power cord to the power outlet at this time.*

1. If your unit is equipped with an internal power supply, go to step 2. Otherwise, insert the barrel type connector end of the AC power cord into the external power supply connector (see figure 19).
2. Insert the female end of the power cord into the internal power supply connector (see figure 19).




Figure 19. Power connector location on rear panel



The router power supply automatically adjusts to accept an input voltage from 100 to 240 VAC (50/60 Hz).

Verify that the proper voltage is present before plugging the power cord into the receptacle. Failure to do so could result in equipment damage.

3. Verify that the AC power cord included with your router is compatible with local standards. If it is not, refer to “[Contacting Patton for assistance](#)” on page 51 to find out how to replace it with a compatible power cord.
4. Connect the male end of the power cord to an appropriate power outlet.
5. Verify that the green *Power* LED is lit (see figure 16).

Congratulations, you have finished installing the SmartNode Gateway Router! Now go to chapter 4, “[Getting started with the SmartNode](#)” on page 41.

Chapter 4 **Getting started with the SmartNode**

Chapter contents

Introduction	42
1. Configure IP address	43
Power connection and default configuration	43
Connect with the serial interface	43
Login	44
Changing the IP address	44
2. Connect the SmartNode to the network.....	45
3. Load configuration	45
Additional information.....	46

Introduction

This chapter leads you through the basic steps to set up a new SmartNode and to download a configuration.

Patton SmartNodes can be used for a wide variety of IP-based network applications. To support and ease the configuration of the SmartNodes configuration, templates for the most important applications are available on the Patton server at www.patton.com/voip.

The main steps for setting up a new SmartNode (as of release 2.00 or 2.10) are shown in figure 20.




Figure 20. Steps for setting up a new SmartNode

1. Configure IP address

Power connection and default configuration

First the SmartNode must be connected to the mains power supply with the power cable. Wait until the 'Run' LED stops blinking and lights constantly. Now the SmartNode is ready.

The factory default configuration for the Ethernet interface IP addresses and network masks are listed in [table 9](#).

Table 9. Factory default IP address and network mask configuration

	IP Address	Network Mask
Interface Ethernet 0 (ETH0)	172.16.40.1	255.255.0.0
Interface Ethernet 1 (ETH1)	192.168.1.1	255.255.255.0

Both Ethernet interfaces are activated upon power-up.

If these addresses match with those of your network, go to section “[2. Connect the SmartNode to the network](#)” on page 45. Otherwise, refer to the following sections to change the addresses and network masks.

Connect with the serial interface

The *Console* port is wired as an EIA-561, RS-232 port. Use the included Model 16F-561 adapter and cable (see [figure 21](#)) between the SmartNode's *Console* port and a PC or workstation's RS-232 serial interface. Activate the terminal emulation program on the PC or workstation that supports the serial interface (e.g. HyperTerm).




Figure 21. Connecting to the terminal

Terminal emulation program settings:

- 9600 baud
- no parity
- 8 bit
- 1 stop bit
- 1 start bit
- No flow control

Login

Accessing your SmartNode via the local console port (or via a Telnet session) causes the login screen to display. Type the factory default login: *administrator* and leave the password empty. Press the *Enter* key after the password prompt.

```
login:administrator
password: <Enter>
172.16.40.1>
```

After you have successfully logged in you are in the operator execution mode, indicated by > as command line prompt. With the commands *enable* and *configure* you enter the configuration mode.

```
172.16.40.1>enable
172.16.40.1#configure
172.16.40.1(cfg)#
```

Changing the IP address

Select the context IP mode to configure an IP interface.

```
172.16.40.1(cfg)#context ip router
172.16.40.1(ctx-ip)[router]#
```

Now you can set your IP address and network mask for the interface *eth0*. Within this example a class C network (172.16.1.0/24) is assumed. The IP address in this example is set to *172.16.1.99* (you should set this to an unused IP address on your network).

```
172.16.40.1(ctx-ip)[router]#interface eth0
172.16.40.1(if-ip)[eth0]#ipaddress 172.16.1.99 255.255.255.0
2002-10-29T00:09:40 : LOGININFO      : Link down on interface eth0.
2002-10-29T00:09:40 : LOGININFO      : Link up on interface eth0.
172.16.1.99(if-ip)[eth0]#
```

Copy this modified configuration to your new start-up configuration. Upon the next start-up the system will initialize itself using the modified configuration.

```
172.16.1.99(if-ip)[eth0]#copy running-config startup-config
172.16.1.99(if-ip)[eth0]#
```

The SmartNode can now be connected with your network.

2. Connect the SmartNode to the network

Depending whether you connect the SmartNode to a host directly or via a hub or switch either straight-through or cross-over cables must be used (see [figure 22](#)).

Note The SmartNode 4520 Series is equipped with Auto-MDX Ethernet ports. Use straight-through or cross-over cables for host or hub/switch connections. The SmartNode 4110 will require the proper cable as it does not have the MDX feature.




Figure 22. Connecting the SmartNode to the network

You can check the connection with the ping command to another host on the local LAN.

```
172.16.1.99(if-ip)[eth0]#ping <IP Address of the host>
```

Respectively from the host: *ping 172.16.1.99*

Note To ping outside your local LAN, you will need to configure the default gateway.

3. Load configuration

Download a configuration note to your PC from the support page of the Patton-Inalp web server (<http://www.inalp.ch/en/support/confignotes/>), which matches your application. Adapt the configuration as described in the configuration note to your network (do not forget to modify the IP address) and copy the modified configuration to a TFTP server. The SmartNode can now load its configuration from this server.

In this example we assume the TFTP server on the host with the IP address 172.16.1.11 and the configuration named *SN.cfg* in the root directory of the TFTP server.

```
172.16.1.99(if-ip)[eth0]#copy tftp://172.16.1.11/SN.cfg startup-config
Download...100%
172.16.1.99(if-ip)[eth0]#
```

After the SmartNode has been rebooted the new start up configuration will be activated.

```
172.16.1.99(if-ip)[eth0]#reload
Running configuration has been changed.
Do you want to copy the 'running-config' to the 'startup-config'?
Press 'yes' to store, 'no' to drop changes : no
```

```
Press 'yes' to restart, 'no' to cancel : yes  
The system is going down
```

Additional information

For detailed information about configuring and operating guidance, set up procedures, and troubleshooting, refer to the *Software Configuration Guide* on the enclosed CD-ROM. On the CD you will also find a freeware TFTP server, which is also available from the <http://solarwinds.net/> web site.

Chapter 5

Monitoring Status

Chapter contents

Status LEDs.....48

Status LEDs

This chapter describes SmartNode gateway router front panel LEDs. [Figure 23](#) shows SmartNode 4520 Series LEDs, [figure 24](#) on page 49 shows SmartNode 4110 Series LEDs. LED definitions are listed in [table 10](#) on page 50.




Figure 23. SmartNode 4520 Series front panels




Figure 24. SmartNode 4110 Series front panels

Table 10. SmartNode LED Indications

LED	Description
Note If an error occurs, all LEDs will flash once per second.	
Power	When lit, indicates power is applied. Off indicates no power applied.
Run	When lit, indicates normal operation. Flashes once per second during boot (startup).
VoIP Link	When lit, indicates the gateway is registered on a gatekeeper, media gateway controller, associated to a remote unit, or has an active VoIP connection. Off indicates the unit is not configured or registered and has no active VoIP connection. Flashing green indicates that the unit is attempting or has failed to associate/register
FXS (each port)	Off indicates on-hook condition. Solid green when off-hook. Flashes to follow ring cadence.
Ethernet (each port)	<ul style="list-style-type: none"> • Link: Lit when Ethernet link is up. • 100M: On when 100-Mbps Ethernet is selected. • Activity: Flashes when data is received or transmitted from the unit to the LAN. • Error condition: All LEDs flashing once per second.

Chapter 6 **Contacting Patton for assistance**

Chapter contents

Introduction	52
Contact information	52
Warranty Service and Returned Merchandise Authorizations (RMAs)	52
Warranty coverage	52
Out-of-warranty service	52
Returns for credit	52
Return for credit policy	53
RMA numbers	53
Shipping instructions	53

Introduction

This chapter contains the following information:

- “Contact information”—describes how to contact Patton technical support for assistance.
- “Warranty Service and Returned Merchandise Authorizations (RMAs)” —contains information about the RAS warranty and obtaining a return merchandise authorization (RMA).

Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems:

- Online support—available at www.patton.com
- E-mail support—e-mail sent to support@patton.com will be answered within 1 business day
- Telephone support—standard telephone support is available five days a week—from 8:00 am to 5:00 pm EST (1300 to 2200 UTC)—by calling +1 (301) 975-1007

Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

Note If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

Out-of-warranty service

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

Returns for credit

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

Return for credit policy

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

RMA numbers

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at **www.patton.com**
- By calling +1 (301) 975-1007 and speaking to a Technical Support Engineer
- By sending an e-mail to **returns@patton.com**

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

Shipping instructions

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

Patton Electronics Company

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

Appendix A **Specifications**

Chapter contents

DSP.....	56
Voice connectivity	56
Connectivity.....	56
Voice processing (signalling dependent).....	56
Fax and modem support.....	56
Voice Signalling.....	57
Voice Routing—Session Router	57
IP services.....	57
Management	58
Operating Environment	58
Operating temperature	58
Operating humidity	58
System.....	58
Compliance.....	58
Dimensions	58
Weight	59
Power supply	59
AC version	59
DC version	59
Power dissipation	59

DSP

One or two 4-channel DSPs

Voice connectivity

2-wire Loopstart, RJ-11/12

Short haul loop 1.1 km @3REN

EuroPOTS (ETSI EG201 188)

Programmable AC impedance, feeding, and ring voltage; On-Hook Voltage 29VDC

Caller-ID Type-1/2 FSK and ITU V.23/Bell 202 generation

Connectivity

2 10/100 Full Duplex/Autosensing Ethernet RJ-45

Voice processing (signalling dependent)

Voice codes:

- G.711 A-Law/ μ -Law (64 kbps)
- G.726 (ADPCM 40, 32, 24, 16 kbps)
- G.723.1 (5.3 or 6.3 kbps)
- G.729ab (8 kbps)
- Transparent pass through

G.168 echo cancellation

8 parallel voice connections

DTMF detection and generation

Carrier tone detection and generation

Silence suppression and comfort noise

Configurable dejitter buffer

Configurable tones (dial, ringing, busy)

Configurable transmit packet length

RTP/RTCP (RFC 1889)

Fax and modem support

G.711 transparent FAX

Fax over IP (FoIP)

T.38 Fax relay (9.6 k, 14.4 k)

Voice Signalling

H.323v4

- RAS, H.225, H.245
- Fast-connect, early H.245
- Gatekeeper autodiscovery
- Alias registration
- Overlap sending
- Empty capability set (call transfer, hold)
- H.323v1 call transfer, hold

ISDN over IP (ISoIP)

- H.323 GW and GK compatible
- H.323 Annex M3
- ISDN/Q-SIG feature tunneling
- ISDN speech, audio and data (Fax Gr 4, UDI 64, RDI 64)

Voice Routing—Session Router

Local switching; Interface huntgroups

Routing Criteria

- Interface
- Calling/called party number
- Time of day, day of week, date
- ISDN bearer capability

Number manipulation functions

- Replace numbers; Add/remove digits
- Multiple remote gateways; PLAR

IP services

IPv4 router; RIPv1, v2 (RFC 1058 and 2453)

Programmable static routes

ICMP redirect (RFC 792); Packet fragmentation

DiffServe/ToS set or queue per header bits

Pocket Policing discards excess traffic

802.1p VLAN tagging

IPSEC AH & ESP Modes
Manual Key; IKE optional
AES/DES/3DES Encryption

Management

Industry standard CLI with local console (CRJ-45, RS-232) and remote Telnet access
TFTP configuration & firmware loading
SNMP v1 agent (MIB II and private MIB)
Built-in diagnostic tools (trace, debug)
Java™ Applet; HPOV Integration with NNM

Operating Environment

Operating temperature

32–104°F (0–40°C)

Operating humidity

5–80% (non condensing)

System

CPU Motorola MPC859 operating at 50 MHz

Memory:

- 32 Mbytes SDRAM
- 4 Mbytes Flash

Compliance

EMC compliance: EN55022 and EN55024

Safety compliance: EN 50950

CE compliance

FCC Part 15 Class A

Dimensions

7.3W x 1.6H x 6.1D in. (18.5H x 4.1W x 15.5D cm)

Weight

See [table 11](#).

Table 11. SmartNode weight and maximum power specifications

SmartNode model	Weight	Maximum power dissipation
4112/4522	30.5 oz (500 g)	6W
4114/4524	30.5 oz (500 g)	8W
4116/4526	24.4 oz (400 g ^a)	12W
4118/4528	24.4 oz (400 g ^a)	15W

a. Excluding external power supply

Power supply

AC version

Internal power supply 100–240 VAC, 50/60 Hz

External power supply: 100–240 VAC, 50/60 Hz

DC version

12 VDC

Power dissipation

See [table 11](#).

Appendix B **Cabling**

Chapter contents

Introduction	62
Serial console	62
Ethernet 10Base-T and 100Base-T	63
Analog FXS	64

Introduction

This section provides information on the cables used to connect the SmartNode and the interface cards to the existing network infrastructure and to third party products.

Serial console

The SmartNode can be connected to a serial terminal over its serial console port, as depicted in [figure 25](#).




Figure 25. Connecting a serial terminal

Ethernet 10Base-T and 100Base-T

Ethernet devices (10Base-T/100Base-T) are connected to the SmartNode over a cable with RJ-45 plugs. Use a cross-over cable to a host, or a straight cable to a hub. See [figure 26](#) (host) and [figure 27](#) on page 64 (hub) for the different connections.

Note The SmartNode 4520 Series is equipped with Auto-MDX Ethernet ports. Use straight-through wired cables for host or hub/switch connections




Figure 26. Ethernet cross-over




Figure 27. Ethernet straight-through

Analog FXS

The router comes with at least two FXS voice ports located on the back of the router. The FXS interfaces are connected to analog devices via cables terminated with RJ-11 connectors.




Figure 28. Connecting an FXS device

Appendix C **Port pin-outs**

Chapter contents

Introduction	66
Console port.....	66
Ethernet 10Base-T and 100Base-T port.....	66
FXS port.....	66

Introduction

This section provides pin-out information for the ports of the SmartNode.

Console port




Figure 29. EIA-561 (RJ-45 8-pin) port

Note Pins not listed are not used.

Ethernet 10Base-T and 100Base-T port

Table 12. RJ-45 socket

Pin	Signal
1	TX+
2	TX-
3	RX+
6	RX-

Note Pins not listed are not used.

FXS port

Table 13. RJ-11 socket

Pin	Signal
3	Ring (-)
4	Tip (+)

Note Pins not listed are not used.